



SUSPENSION CONTROL VALVES


Air Bag Control Valve – Manual Operation



INFORMATION:

- Commonly used to control the inflation & deflation of air suspension bags
- Allows for movement of trailer back to dock without re-inflating air bags
- Operates with all air suspension systems
- Pull to manually exhaust air from air bags

Push to refill air bags from reservoir



PART NUMBER	PORT SIZES (NPT)	
	Inlet	Outlet
17610	3/8"	3/8"