




SUSPENSION CONTROL VALVES

Air Bag Control Valve – Automatic Operation



INFORMATION:

- Commonly used to control the inflation & deflation of suspension air bags
- Normally used with 110587 Pilot Valve
- Operates with all air suspension systems but not recommended for suspensions that exhibit dock walk
- Manually operated to exhaust air from the air ride springs
- Automatically resets to fill the air springs when the trailer parking brakes are released
- **13-A KNOB INCLUDED**



PART NUMBER	PORT SIZES (NPT)		
	Supply	Outlet	Exhaust
110555	1/4"	1/4"	1/4"